



**Main products**

**Spare part list**

5901516900

138113 - 0186 - C-MBS635-X - -

Spare	Description	additional	Item	Abb.	ConstructStatus
5901516001	Adjusting knob		2	A	*
5901516002	Driven wheel cpl.		17,18	A	*
7901510701	Saw Band 733mm / 12,7mm / 0,4mm / 14 -18 Z/Z		21	A	*
5901516003	Shield		22	A	*
3910101043	lens head screw M4x10 torx part 2	M4x10	24	A	*
5901516004	Driving wheel		41	A	*
5901516005	Engine	Motor 785	45	A	*
5909234003	Handle	M8x10	49	A	*
01091103	HEXAGON STUD WRENCH SIZE 2,5	SW2.5	50	A	*



5901516900

Cordless Metal Band  
Saw C-MBS635-X  
scheppach (DIY)

**Main products**

**Spare part list**

5901516900

138113 - 0186 - C-MBS635-X - -

Spare	Description	additional	Item	Abb.	ConstructStatus
5901516006	Discharge protection board		54	A	*
5901516007	Microswitch	25A 36V	59	A	*
5901516008	Brush		66	A	*
7909201708	Battery SBP2.0 scheppach (DIY)		o.Abb.	A	*
7909201709	Battery SBP4.0 scheppach (DIY)		o.Abb.	A	*
7909201710	Battery Charger SBC2.4A scheppach (DIY)		o.Abb.	A	*
7909201712	Twincharger SDBC2.4A scheppach (DIY)		o.Abb.	A	*
7909201713	Twincharger SDBC4.5A scheppach (DIY)		o.Abb.	A	*
7909201711	Battery Charger SBC4.5A scheppach (DIY)		o.Abb.	A	*
7909201720	Starter-Kit 2.0 SBSK2.0 scheppach (DIY)	2Ah battery + 2,4A battery charger included	o.Abb.	A	*
7909201721	Starter-Kit 4.0 SBSK4.0 scheppach (DIY)	4Ah battery + 2,4A battery charger included	o.Abb.	A	*

!!! Do you know: From now on you can view spare parts lists in our spare parts shop and order spare parts and accessories directly. More information can be found here: <https://www.scheppach.com/Shop.aspx>