

# scheppach

**5909235900**


cordless angle grinder  
BC-AG125-X  
scheppach (DIY)



# Scheppach

5909235900

cordless angle grinder  
BC-AG125-X  
scheppach (DIY)





**Main products**

**Spare part list**

5909235900

372916 - 0299 - BC-AG125-X - -

Spare	Description	additional	Item	Abb.	ConstructStatus
5909234001	Disc cover		1	A	*
5909234002	Flange set		2,3	A	*
7903806704	cutting disc set 12 pcs. scheppach (DIY)	Ø125	3	A	*
5909235001	spindle		7	A	*
5909235002	big gear		13	A	*
5909235004	lock pin		20	A	*
5909235003	gear		22	A	*
5909235005	armature		25	A	*
5909235006	stator		28	A	*
5909235007	switch cover		31	A	*
5909235008	Controller		34	A	*
5909234003	Handle	M8x10	36	A	*
5909234004	Wrench		37	A	*
7909201708	battery SBP2.0 scheppach (DIY)		o.Abb.	A	*
7909201709	battery SBP4.0 scheppach (DIY)		o.Abb.	A	*
7909201710	battery charger SBC2.4A scheppach (DIY)		o.Abb.	A	*
7909201712	twincharger SDBC2.4A scheppach (DIY)		o.Abb.	A	*
7909201713	twincharger SDBC4.5A scheppach (DIY)		o.Abb.	A	*
7909201711	battery charger SBC4.5A scheppach (DIY)		o.Abb.	A	*
7909201720	Starter-Kit 2.0 SBSK2.0 scheppach (DIY)	2Ah battery + 2,4A battery charger included	o.Abb.	A	*
7909201721	Starter-Kit 4.0 SBSK4.0 scheppach (DIY)	4Ah battery + 2,4A battery charger included	o.Abb.	A	*

!!! Do you know: From now on you can view spare parts lists in our spare parts shop and order spare parts and accessories directly. More information can be found here: <https://www.scheppach.com/Shop.aspx>